

A Leading Manufacturer of Quality Thermocouple and RTD Assemblies Since 1972

Industrial Thermocouples

Thermo Sensors Industrial thermocouples are widely used in process industry applications. Thermocouples are generally selected by determining the particular conditions under which it must perform. These conditions which have recommended wire and material selections and are grouped in types.



Thermo Sensors thermocouple element types include:

- Type E Chromel-Constantan Thermocouple
- Type J Iron-Constantan Thermocouple
- Type K Chromel-Alumel Thermocouple
- Type N Nicrosil-Nisil Thermocouple
- Type R Platinum-Platinum 13% Rhodium Thermocouple
- Type S Platinum-Platinum 10% Rhodium Thermocouple
- Type B Platinum 6% Rhodium-Platinum 30% Rhodium Thermocouple
- Type T Copper- Constantan Thermocouple

The wire gauge and recommended temperature ranges are of various sizes as well.

Please refer to our order guide to assist in determining your needs. We can also provide technical design assistance and application suggestions. Give us a call.

*Metal-Ceramic Protecting Tube with Fitting

Single Thread Tube



Also available without 3/4" Instrument Thread

Part Number	
MCT580F-(L)	

Thermo Sensors Corporation Copyright 2012 www.thermosensors.com



A Leading Manufacturer of Quality Thermocouple and RTD Assemblies Since 1972

Without Instrument Thread (not shown) MCT580-(L) Specify "L" in Inches

Double Thread Tube




Process Thread	Ritting Material	Part Number
1" NPT	C.S.	MCT581H-(L)
(Standard)	ST.ST.	MCT581HSS-(L)
1 1/4" NPT	C.S.	MCT581K-(L)
	ST.ST.	MCT581KSS-(L)
1 1/2" NPT	C.S.	MCT581M-(L)
	ST.ST.	MCT581MSS-(L)
2" NPT	C.S.	MCT581P-(L)
	ST.ST.	MCT581PSS-(L)

How to Order:

Select Desired Part Number and Specify "L" in Inches **Example:** MCT581H-18

*Metal-Ceramic Protecting Tube Assembly



Thermo Sensors Corporation Copyright 2012 www.thermosensors.com



A Leading Manufacturer of Quality Thermocouple and RTD Assemblies Since 1972

ANSI	Element	Ordering Code			Process Thread
Calibration	Gauge	Туре	Head	"L"	
Iron/Constantan	8 AWG	J8MCT	T Below	Specify in	Specify "Order Code" from Table
Type J	14 AWG	J14MCT		Inches	Below
Chromel/Alumel	8 AWG	K8MCT			
Туре К	14 AWG	4 AWG K14MCT			

Terminal Head Options				
Head	Terminal Block	Specify		
Cast Iron	Single	A		
Screw Cover	Dual	AD		
Cast Aluminum	Single	B		
Screw Cover	Dual	BD		

Process Thread Options				
Thread	Order Code			
	Carbon Steel	Stainless Steel		
1" NPT	Н	HSS		
1 1/4" NPT	К	KSS		
1 1/2" NPT	М	MSS		
2" NPT	Р	PSS		

How to Order:

- 1. Select the type and gauge of thermocouple desired from the first three columns of the table. Specify by "Type" under ordering code.
- 2. Select a head from the "Terminal Head Options" table and place its code letter next.
- 3. Specify "L" in inches and place after head code.
- 4. Specify option from "Process Thread Options" table.

For Example:

<u>K8MCT</u> - <u>B</u> - <u>24</u> - <u>HSS</u>

Type Head "L" Option

Thermo Sensors Corporation Copyright 2012 www.thermosensors.com